

## Early - Honda Valkyrie Instructions

Please read and ensure you fully understand the main lift instructions before commencing, if in any doubt please contact us for advice!

Place the mounts on the lifting arm approximately 30mm from each end of the lift arm then firmly lock in place using a 13mm wrench.

Next with the motorcycle on its side-stand push the lift into and under the bike from the opposite side ensuring the Rear Mount locates under the frame at the back of the gearbox and use the “U” bolt provided to go over the frame and lock the bike firmly to the mount.

Important.

Ensure that the Main Lifting arm is completely inline with the centre line of the bike/tyres, Failure to do this could be dangerous!

Now check that the Front Mount is sitting correctly under the front of the Crankcase.

When satisfied all is in the correct position manually start turning the screw-shaft clockwise using a 22mm socket until the mounts make contact with the bike.

At this point assist the bike to the vertical position and continue turning the screw-shaft until full contact is made.

Next, do a final check that the mounts are in the correct position and the bike can be fully raised.

Always use tie down ratchet straps or similar for maximum Safety and Stability!!

